

FOOTING INSTALLATION INSTRUCTIONS:

- STEP 1: IDENTIFY THE COMPONENTS SUPPLIED USING THE PACKING LIST. CONTACT US AS SOON AS POSSIBLE IF ANY PARTS ARE MISSING.
- STEP 2: SLIDE THE INTERNAL SLEEVE 500MM INSIDE THE TOP SECTION.
- STEP 3: THEN, USING THE HOLES IN THE TOP SECTION DRILL 3 X HOLES INTO 5MM Ø HOLES INTO THE INTERNAL SLEEVE AND SCREW 2 X 14g X 35MM PAN HEAD TEK SCREWS.
- STEP 4: THEN JOIN THE BOTTOM SECTION TO THE INTERNAL SLEEVE AND REPEAT STEP 3.
- STEP 5: SLIDE IN THE POST SPIGOT INTO THE GOAL POST BOTTOM SECTION AND REPEAT STEP 3.
- REPEAT STEP 2 3 FOR BEHIND/POINT POST ASSEMBLY
- STEP 6: THEN POSITION THE PIN AT THE SPIGOT INTO THE HINGE BRACKET.
- STEP 7: USING A LIFTING AID RAISE THE POST UP.
 YOU CAN USE CROSS BAR ATTACHED ACROSS A TRACTOR REAR TO
 RAISE OR LOWER THE POSTS.
- STEP 8: THEN FIX THE ASSEMBLY USING M20 NUT AND WASHER. THEY SHOULD BE PROPERLY TIGHTENED.
- **STEP 9: INSTALL FOOTING COVERS OVER THE BASE**





